

# Entering your tariff data

## Tariff Data

Once you have connected your system, the app will prompt you to enter your tariff data.

If you are with Octopus Energy, you need to log into your Octopus account and create an API key which is then copied and pasted into the app.

We currently support most energy suppliers and tariffs, but if you have any issues then please email us at [hello@smug.energy](mailto:hello@smug.energy)

## Feed In Tariff (FIT) systems

In order to benefit from the optimisation savings, you will need to be receiving payments for exported electricity. Those using older FIT tariff - you can manually configure these as a fixed export tariff. If you need help setting this up, please email us at [hello@smug.energy](mailto:hello@smug.energy)

You might like to be aware that there are export tariffs such as Octopus Flux, which pay a fair bit more than the FIT export rate, so it might be worth considering swapping, particularly as Smug will help you to maximise the export income from a time-of-use tariff.

Here is a link if you'd like to switch to Octopus: <https://share.octopus.energy/cute-calf-246> - your savings are likely to be significantly higher on a variable export tariff.



## Tariff details

### Import tariff

Tariff name

Agile Octopus

Standing charge

47.85p / day

All rates include VAT

### Export tariff

Tariff name

Agile Outgoing Octopus

Standing charge

0p / day

All rates include VAT



Get help



Home



Account

Once you have successfully set up your tariff, you should see the above.

Revision #2

Created 18 February 2025 13:43:46 by Krisztian Hunter

Updated 18 February 2025 14:15:42 by Krisztian Hunter